

# OPERATION INSTRUCTIONS Crestron 5-i MMXV


This console is equipped with a PC computer and Doc Cam connected to digital video projector. HDMI and VGA laptop connections are available

The Crestron **Touch Panel** is utilized for control.  
If the panel has gone to sleep, touch it to resume.  
Press **Power On System** to get started.



Once the projector has warmed up the **PC** computer will be selected.  
Other devices may be selected in the left column.

**Laptop display cables** are available in the cubby beside the touch panel, or in the cabinet drawer.



When selected, controls for **DVD or VCR** will appear on the touch screen.  
**Audio Volume** can be adjusted with the arrow buttons on the right.  
**Projector Mute** can be used to temporarily hide your presentation.



**When finished with your presentation**  
**Please Press Exit to Power Off System**  
**Need help? Call Classroom Support at 878-6670**