# OPERATION INSTRUCTIONS
Crestron Caudell- MMXV

This console is equipped with a PC computer and Doc Cam connected to digital video projector. HDMI and VGA laptop connections are available

The Crestron **Touch Panel** is utilized for control.
If the panel has gone to sleep, touch it to resume.
Press **Power On System** to get started.

Once the projector has warmed up the **PC** computer will be selected.
Other devices may be selected in the left column.

Laptop display cables are available in the cubby beside the touch panel.

When selected, controls for **DVD** will appear on the touch screen.
Audio Volume can be adjusted with the arrow buttons on the right.
Projector Mute can be used to temporarily hide your presentation.

When finished with your presentation
Please Press Exit to Power Off System

Need help? Call Classroom Support at 878-6670