

OPERATION INSTRUCTIONS Bulger MMXXIII

This console is equipped with a PC computer and a Document Camera connected to a digital video projector. HDMI and VGA laptop connections are available.


The Crestron **Touch Panel** is utilized for control.
If the panel has gone to sleep, touch it to resume.
Press **Power On Room** to get started.



Once the projector has warmed up the **PC** Computer will be automatically selected.

Other inputs may also be selected in the left column.


Audio Volume can be adjusted with the control buttons on the right.



Laptop cables are available in the in the console drawer. Cables can be connected at the plate next to the touch panel.

Projector Mute can be used to temporarily hide your presentation.

Please note- This **Will Not** turn off the projector.



**When finished with your presentation
Please Press Power Off System**

Need help? Use the black phone on the console side, or call (716) 878-6670.