


OPERATION INSTRUCTIONS Crestron 4-i MMXX

This console is equipped with a PC computer and Doc Cam connected to digital video projector. HDMI and VGA laptop connections are available


The Crestron **Touch Panel** is utilized for control.
If the panel has gone to sleep, touch it to resume.
Press **Power On System** to get started.



Once the projector has warmed up the **PC** Computer will be automatically selected.


Laptop inputs and the **Doc Cam** may also be selected in the left column.

Laptop display cables are available in the cubby beside the touch panel.



Audio Volume can be adjusted with the control buttons on the right.

Projector Mute can be used to temporarily hide your presentation.



**When finished with your presentation
Please Press Power Off System**

Need help? Call Classroom Support at 878-6670