OPERATION INSTRUCTIONS Rock 300 MMXXII

This console is equipped with a PC computer and a Doc Cam connected to a digital video projector. HDMI and VGA laptop connections are available.

The Extron **Touch Panel** is utilized
for control.
If the panel has gone to sleep, touch it
to resume.
Press **Power On Room** to get started.

Once the projector has warmed up the **PC**
computer will be selected.
The Doc Cam and Laptop inputs may be
selected in the top row.

Laptop display cables are available in the
cubby beside the touch panel.

Audio Volume can be adjusted with
the knob at the bottom of the touch panel.

Projector Mute can be used to temporari-
ly hide your presentation. (this DOES NOT
power off the projector.)

When finished with your presentation

Please Press System Off to turn off System

Need help? Call Classroom Support at 878-6670